



# APECS<sup>®</sup> DPG-2223-00X Digital Controllers

- Automatic calibration of remote speed potentiometer
- Isochronous speed control
- Droop operation: 0 to 10% of set speed with 1/10 percent resolution
- User friendly, operator adjustable
- Precision frequency control: 0.25%
- Superior temperature stability
- Reverse battery protection
- Input voltage range: 9–30 Vdc
- Smoke control on start up
- Remote setup
- Serial communications port
- Paralleling input
- ILS speed adjustment range:  $\pm 5\%$

## DESCRIPTION

The DPG-2223-00X digital controller is used primarily to govern diesel or gas fueled engines of generator sets. This microprocessor-based, digital controller performs across a wide speed range and allows adjustment of all controller features through the built-in user interface. Properly tuned, this controller delivers fast engine response to speed or load change while providing precise stable isochronous operation.

Separately programmable Proportional, Integral, and Derivative gains are provided for tailoring controller response to many engine applications. Other adjustments include acceleration and deceleration ramp rates, startup and torque limits, idle speed set, and idle hold time.

The controller can also provide droop speed control with 100 user-selectable droop levels. The controller's internal FAILSAFE reacts instantly to loss of the engine speed signal or loss of remote speed potentiometer signal.

## ACTUATOR COMPATABILITY

DYNA 2000 DYNA 2500  
 DYNA 7000 DYNA 70025  
 DYNA 8000 DYNA 8200 DYNA 8400  
 DYNA 10141  
 APECS 0150 APECS 0250 APECS 0300  
 Power Flow Series Gas Valves  
 APECS Linkage Free Integral Type

## OTHER MODELS AVAILABLE

DPG-2100 Series – For Genset Applications  
 DPG-2300 Series – For Off-Road Applications  
 DPG-2400 Series – EFC Valve Applications

## CALIBRATION TOOL

DPG Calibration Kit P/N 8447-1003

# SPECIFICATIONS

The controller's main electrical and mechanical specifications are listed below along with several performance characteristics.

## Electrical

<b>Operating Voltage Range:</b>	9–30 Vdc *
<b>Rated Output Current:</b>	7 A Maximum (continuous)
<b>Maximum Surge Current:</b>	14 A (not to exceed ten seconds)
<b>Connections:</b>	Terminal strip with 14 terminals
<b>Input Signal from the Magnetic Pickup:</b>	2.0 Vac RMS minimum during cranking

(\*) All cabling for this unit is limited to less than 30m (98.4').  
Power cabling is limited to less than 10m (32.8') in total length.  
See wiring diagram in User Manual 36522 for specific cable types required.

## Mechanical

<b>Ambient Operating Temperature:</b>	-40°F to +185°F (-40°C to +85°C)
<b>Sealing:</b>	Oil, water, and dust resistant via conformal coating and die cast enclosure
<b>Weight:</b>	12 oz. (341 g)
<b>Connection:</b>	14-terminal Euro-style connector
<b>Mechanical Vibration:</b>	Suitable for mounting per SAE J1455; 1 to 500 Hz, 5G amplitude

## Performance

<b>Temperature Stability:</b>	0.007 Hz @ 158°F (70°C)
<b>Steady State Speed Band:</b>	± 0.25% over ambient operating temperature range
<b>Engine Speed Measurement Range:</b>	10 MPU Hertz to 14,000 MPU Hertz
<b>Governing Speed Range:</b>	500 MPU Hertz to 11,000 MPU Hertz
<b>ILS Input Voltage Measurement Range:</b>	2.3–2.7 Vdc
<b>ILS Input Speed Adjustment Range:</b>	± 5% around the set speed
<b>Droop Adjustment Range:</b>	0–10% of the set speed
<b>Droop Setting Resolution:</b>	Tenths of a percent

# PARAMETER REFERENCE

The following table lists each of the parameters and their default, minimum, and maximum values. Several of the parameters have minimum and maximum values set by other parameters. *Speed* and *Rate* values are shown as Hertz values.

## DPG-2223-00X Parameter List

PARAMETER NAME		DEFAULT	MINIMUM	MAXIMUM
1. No. of Flywheel Teeth	-001	0	0	0
	-002	0	0	572
2. Remote Speed Min		1000	10	Remote Speed Max
3. Remote Speed Max		1000	Remote Speed Min	11,000
<b>4. Set Speed A</b>		<b>1000</b>	<b>Set Speed A Min</b>	<b>Set Speed A Max</b>
5. Idle Speed		500	Idle Speed Min	Idle Speed Max
<b>6. Proportional</b>		<b>25</b>	<b>1</b>	<b>99</b>
<b>7. Integral</b>		<b>50</b>	<b>0</b>	<b>99</b>
<b>8. Derivative</b>		<b>25</b>	<b>0</b>	<b>99</b>
9. OVG @ Remote Speed Min		20	1	99
10. OVG @ Remote Speed Max		0	0	99
<b>11. OVG @ Set Speed A</b>		<b>20</b>	<b>1</b>	<b>99</b>
12. OVG @ Idle Speed		20	1	99
<b>13. Gain Factor</b>		<b>20</b>	<b>1</b>	<b>99</b>
<b>14. Speed Filter</b>		<b>16</b>	<b>1</b>	<b>24</b>
15. Idle Hold Time		0	0	9999
16. Accel Rate		1000	1	11000
17. Decel Rate		1000	1	11000
18. Startup Rate		1000	1	11000
19. Startup Limit		1000	0	1000
20. Torque Limit		1000	0	1000
21. Integral Low Limit		0	0	Integral High Limit
22. Integral High Limit		99	Integral Low Limit	99
23. % Droop		0	0	100
24. No Load Cal		0	0	1000
25. Full Load Cal		1000	0	1000
26. Password		0	0	99
27. Over Speed Limit	-001	100	0	100
	-002	15000	10	15000
28. Set Speed A Min		10	10	Set Speed A
29. Set Speed A Max		11000	Set Speed A	11000
30. Idle Speed Min		10	10	Idle Speed
31. Idle Speed Max		11000	Idle Speed	11000
32. Duty Cycle Limit		95	10	95
33. E1 Handler Select	-001	0	0	1
	-002	0	0	2
34. Startup Speed		1000	10	11000
35. Startup Duty Cycle		30	5	95
36. Speed Pot Action		0	0	1

PO Box 1519  
Fort Collins CO, USA  
80522-1519  
1000 East Drake Road  
Fort Collins CO 80525  
Ph: +1 (970) 482-5811  
Fax: +1 (970) 498-3058

**Distributors & Service**  
Woodward has an international network of distributors and service facilities. For your nearest representative, call the Fort Collins plant or see the Worldwide Directory on our website.

**Corporate Headquarters**  
Rockford IL, USA  
Ph: +1 (815) 877-7441

[www.woodward.com](http://www.woodward.com)

This document is distributed for informational purposes only. It is not to be construed as creating or becoming part of any Woodward Governor Company contractual or warranty obligation unless expressly stated in a written sales contract.

## EUROPEAN COMPLIANCE FOR CE MARKING

### EMC DIRECTIVE

Declared to 89/336/EEC COUNCIL DIRECTIVE of 03 May 1989 on the approximation of the laws of the Member States relating to electromagnetic compatibility. See the Declaration of Conformity in User Manual 36522.

### EMC LIMITATIONS

#### Cabling

All cabling for this unit is limited to less than 30m (98.4').

Power cabling is limited to less than 10m (32.8') in total length from its source; power is intended to be from a local bus structure. The control is not intended to have a power bus that is derived from a plant-wide distribution system, remote source, or similar "mains" type distribution systems. The power to the control should also be a dedicated circuit, directly to the battery or source via a power and return wire that are routed together.

See User Manual 36522 for additional regulatory information, limitations, and wiring diagrams with specific, required cable types.

#### Power Bus

The power bus is intended to be a local bus and to have inductive load kickback events suppressed. Therefore, the control's power input is not designed to withstand a charging system load dump, heavy inductive kickbacks, or heavy surge type pulses. If the control is installed outside its intended usage, as described in this manual, centralized voltage pulse suppression should be implemented to protect the control and other components on the bus. (See the installation instructions in User Manual 36522.)

#### COMM Port

The COMM port is intended to be a service port, with only temporary connection during service or initial configuration. The COMM port is susceptible to some EMC phenomena and possible unintentional battery return currents.

1. Battery return (B-) is also the communication signal common; typically PCs connect the communication signal's common to protective earth. The PC grounding can provide an unintended return path for B- currents. If B- and the PC are grounded to protective earth, a communication isolator should be used between the PC and the control. Damage to the PC or control, and/or unintended operation may result from a broken battery return wire or the parallel path.
2. The pins inside the COMM port plug are susceptible to damage by ESD discharges, static electricity arcs. Care should be taken not to touch them with tools or put fingers into the port. Always touch your hand or tool to a grounded piece of metal (discharge ESD) before coming in contact with the COMM port.
3. The input is susceptible to RF noise such as switching transients and transmitter signals coupled into the communication cable. Cable orientation and short cable length may be used to eliminate these issues, depending on the severity of the environment.

## RELATED DOCUMENTATION

User Manual 36522

For more information contact: